

(c) ReTiSoft Inc.

www.retisoft.ca

Sealevel 110E



Manufacturer: Sealevel Systems Inc.
 Model Number: Sealevel-110E
 Web Address: www.sealevel.com

Control and monitor four optically isolated inputs and four Reed relay outputs via any 10/100BaseT Ethernet connection with the eI/O-110E digital I/O module. Inputs can range from 5-30VDC and provide 3500VDC (2500VAC RMS) isolation to ground, while the Reed relays provide long-life switch closures well suited to low-current devices. Each Reed relay has a discrete common and each pair of inputs share a common for easy field wiring via removable 3.5mm terminal blocks.

110E I/O Device: Commands

• **SM_WriteDigitalOutputs(digitalID, status)** - Set the status of a digital output.

digitalID	Integer	Digital output identifier. Range of values: 1 to 4.
status	Boolean	Desired status of the digital output.

• **SM_ReadDigitalInputs(digitalID)** - Read the status of a digital input.

digitalID	Integer	Digital input identifier. Range of values: 1 to 4.
-----------	---------	--

I/O Error

• **IOError(number, description)** - Error occurred during command execution.

number	Integer	Error number.
description	String	Error description.

ReTiSoft Inc.
 366 Revus Avenue, Unit 21
 Mississauga, Ontario, Canada, L5G-4S5
 Main: 647-724-2398 Europe: 33-9-7518-0225
 Web: www.retisoft.ca Email: info@retisoft.ca